

TRK		FUNCTION	
TIP	RING	Pr.	
BK	BL	1	
BK	OR	2	
BL	BR	3	
GR	BK	4	
BK	SL	5	
YL	BL	6	
YL	OR	7	
GR	YL	8	
YL	BR	9	
----	----	10	No connection
Spares - Not connected: RD-BR RD-OR RD-SL RD-GN			