


SWITCH MATRIX

Dedicated Grounded Switches	Row	Column	Color								Flipper Grounded Switches	
			1 White	2 Green-Red	3 Green-Orange	4 Green-Yellow	5 Green-Black	6 Green-Blue	7 Green-Violet	8 Green-Gray		9 Gray-White
Orange-Brown J205-1	(1)	1 White-Brown J206-1 U18-11	11 Right Inlane	21 Slam Tilt	31 Left Jet Bumper	41 Dead End	51 Gumball Popper Lane	61 Lower Skill	71 Not Used	81 Lower Right Magnet	91 Clock 15 Minutes	Black-Green J906-1 Right Flipper End of Stroke F1
Left Coin Chute D1	(2)	2 White-Red J206-2 U18-9	12 Right Outlane	22 Coin Door Closed	32 Right Jet Bumper	42 The Camera	52 Hitch-Hiker	62 Center Skill	72 Auto-Fire Kicker	82 Not Used	92 Clock 0 Minutes	Blue-Violet J905-1 Right Flipper Opto F2
Orange-Red J205-2	(3)	3 White-Orange J206-3 U18-5	13 Start Button	23 Buy-In Button	33 Lower Jet Bumper	43 Player Piano	53 Left Ramp Enter	63 Upper Skill	73 Right Ramp	83 Left Magnet	93 Clock 45 Minutes	Black-Blue J906-3 Left Flipper End of Stroke F3
Center Coin Chute D2	(4)	4 White-Yellow J206-4 U18-7	14 Plumb Bob Tilt	24 Always Closed	34 Left Slingshot	44 Mini Playfield Enter	54 Left Ramp	64 Upper Right 5 Million	74 Gumball Popper	84 Center Lock	94 Clock 30 Minutes	Blue-Gray J905-2 Left Flipper Opto F4
Orange-Black J205-3	(5)	5 White-Green J206-5 U19-11	15 Right Trough	25 Far Left Trough	35 Right Slingshot	45 Mini Playfield Left (2)	55 Gumball Geneva	65 Power Payoff (2)	75 Mini Playfield Top	85 Upper Lock	95 Clock Hour 1	Black-Violet J906-4 Upper Right Flipper End of Stroke F5
Right Coin Chute D3	(6)	6 White-Blue J206-7 U19-9	16 Center Trough	26 Trough Proximity	36 Left Outlane	46 Mini Playfield Right (2)	56 Gumball Exit	66 Middle Right 5 Million	76 Mini Playfield Exit	86 Not Used	96 Clock Hour 2	Black-Yellow J906-3 Upper Right Flipper Opto F6
Orange-Yellow J205-4	(7)	7 White-Violet J206-8 U19-5	17 Left Trough	27 Ball Shooter	37 Left Inlane 1	47 Clock Millions	57 Slot Proximity	67 Middle Left 5 Million	77 Middle Right 5 Million	87 Gumball Enter	97 Clock Hour 3	Black-Gray J906-5 Upper Left Flipper End of Stroke F7
4th Coin Chute D4	(8)	8 White-Gray J206-9 U19-7	18 Outlane	28 Rocket Kicker	38 Left Inlane 2	48 Lower Left 5 Million	58 Slot Kickout	68 Lower Right 5 Million	78 Upper Left 5 Million	88 Lock Lower	98 Clock Hour 4	Black-Blue J905-5 Upper Left Flipper Opto F8

J20XX = CPU Board, J90XX = Fliptronic II Board * Located on 8 Driver P.C.B., A-16100, in backbox.

SWITCH LOCATIONS



MINI-PLAYFIELD, TOP AND BOTTOM RAMP SWITCH LOCATIONS

Item	Switch Part #	Where Used
F1	5490-12451-00	* Lower Right Flipper EOS
F2	A-15894	* Lower Right Flipper Cabinet
F3	5490-12451-00	* Lower Left Flipper EOS
F4	A-15894	* Lower Left Flipper Cabinet
F5	5490-12451-00	* Upper Right Flipper EOS
F6	A-15894	* Upper Right Flipper Cabinet
F7	5490-12451-00	* Upper Left Flipper EOS
F8	A-15894	* Upper Left Flipper Cabinet
11	5647-12693-19	Right Inlane
12	5647-12693-19	Right Outlane
13	20-9663-1	Start Button
14	A-15361	* PlumbBob Tilt
15	5647-12693-08	Right Trough
16	5647-09957-00	Center Trough
17	5647-09957-00	Left Trough
18	5647-12133-12	Outlane
21	27-1066	* Slam Tilt
22	5643-09288-00	* Coin Door Closed
23	20-9663-9	Buy-In Button
24	Always Closed
25	5647-09957-00	Far Left Trough
26	A-16528	† Trough Proximity
27	5647-12693-04	Ball Shooter
28	5647-12693-55	Rocket Kicker
31	SW-11A-37	Left Jet Bumper
32	SW-11A-37	Right Jet Bumper
33	SW-11A-37	Lower Jet Bumper